



Typ 4 ———



Typ 3	
CC30	
	350mA
	400mA
	450mA
	500mA
	550mA
	600mA
	650mA
	700mA

Verwendung der DIP-Schalter nur nach Netz-Aus
Use of DIP Switch only after mains off