



Typ 2 ———
 Typ 3 - - - - -



	Typ 2	Typ 3
	CC21	CC30
	150mA	350mA
	200mA	400mA
	250mA	450mA
	300mA	500mA
	350mA	550mA
	400mA	600mA
	450mA	650mA
	500mA	700mA

4000K

4000K

3500K

3000K

4000K

4000K

3500K

3000K

4000K

4000K

3500K

3000K

4000K

4000K

3500K

3000K

optional MC, siehe Seite 1
 Einstellungen Lichtfarbe

Verwendung der DIP-Schalter nur nach Netz-Aus
 Use of DIP Switch only after mains off